

9284..... TekNek CM 300FEC Cleaner For Film

S/N: 3175 & 1993

12" Wide 110V *Two [2] Available*



05



1. ADHESIVE ROLL CLEARING (T) SWITCH OFF MACHINE. OPEN HOUSING LAYER FROM TOP AND BOTTOM. REPLACE ROLL AND RESTART.
2. ADHESIVE ROLL REP. SCENE WHEN FITTING NEW ROLL. S END THAT MATERIAL WIND. 3 IS OFF TO DIRECTION OF ROTATION.
3. WWT: STATIC BAR CLEARING. WASH MINIMUM DISCONNECT 3 BARS LOCATED IN EXIT SLIT. USE A SOFT DRY BRUSH.

DESIGNED AND MANUFACTURED BY

TEKNE
ELECTRONICS
LIMITED



MODEL

CM-300FEG

SERIAL NO.

3 1 7 6

SUPPLY

110

FREQ.

60

AUTO FILM CLEANER

CLEAN MACHINE



INSTRUCTIONS

1. Connect the power cord to the wall outlet.
2. Turn the power switch to the 'ON' position.
3. Place the film in the machine and start the cleaning cycle.



TEKNEK

MADE IN THE U.S.A.

MODEL 1000-1000-1000





MODEL

CW 300FEU

SERIAL NO.

5993

SUPPLY

100

FREQ.

60

**Remember...don't close the window
use the BACK FUNCTION**

